

EnnoLogic Light Meter eL200K

Quick-Start Guide

WHEN YOUR LIGHT METER ARRIVES

1 Open the Package

When you open the package, you should find your manual, your light meter, its carrying case, an analog output interface cable, and 4x AA batteries. The manual is located inside the lid, behind the foam.



2 Install the Batteries

Use a screwdriver to unscrew the battery compartment cover on the back of the unit and insert the four AA batteries included in the package. Make sure the polarity is correct (match the positive and negative terminals according to the diagram inside the battery compartment.) Reinstall the battery cover.

TAKE IT FOR A SPIN

Turning the Light Meter On and Off

Press the **POWER** key to turn the meter on.
Press it again to turn it off.

After 5 minutes without use the meter will automatically power off.



Switching Units

Press the **UNITS** key to switch between Fc (foot candle) and Lux.

Backlight

Press the **BACKLIGHT** key to turn the backlight on or off.



Tracking the Maximum, Minimum and Average Values

Press the **MAX** key to capture the maximum light intensity. The reading will remain unchanged until a higher reading is detected. Press the **MAX** key again to capture the minimum reading (MIN), and press it again to display average readings (AVG). Press the **MAX** key one more time to exit this mode.

ADVANCED FEATURES

Hold Function

Press the **HOLD** key to enter and exit data hold mode. When in Hold mode, the displayed value will no longer update.

Disable Auto-Power-Off

To disable the Auto-Power-Off feature hold the **UNITS** key down while turning the meter on, then release the **UNITS** key. You will see the Power symbol appear on the LCD, indicating that the auto-power-off feature has been disabled.



External Power

The unit can be powered with the USB cable provided, connected to a standard USB power adapter or port.

WANT TO LEARN MORE?

You'll find more information in the **user manual downloadable at our website.**

ennoLogic[®]

QUESTIONS? NEED ADDITIONAL SUPPORT?

support@ennoLogic.com
(541) 525-9175